





SAFETY RECALL

Riveted Blade in the following series of Cuisinart® Food Processors:

- CFP-9 • CFP-11 • DFP-7 • DFP-11 • DFP-14 • DLC-5 • DLC-7 • DLC-8 • DLC-10 • DLC-XP • DLC-2007 • DLC-2009 • DLC-2011 • DLC-2014 • DLC-3011 • DLC-3014 • EV-7 • EV-10 • EV-11 • EV-14 • KFP-7 • MP-14

The riveted blade may crack and a piece of the blade could detach, which may result in a **laceration hazard**.

TO DETERMINE IF YOUR FOOD PROCESSOR BLADE IS PART OF THE RECALL:

Recalled	Not Recalled
<p>1. Check the blade to see if there are rivets ...</p>  <p>2. If your blade has rivets, check the Model or Series number of your Food Processor, as shown on the bottom of the Food Processor (see below). If the number starts with any of the above (which may be followed by a suffix), STOP using the riveted blade immediately. Call the Customer Service number or register Online to receive a replacement blade (see below).</p>  <p>Bottom of Food Processor</p>	<p>1. If the Model number ends in a Y as shown on the front panel of the box ...</p>  <p>OR</p> <p>There are NO RIVETS on the blade ...</p>  <p>2. Your Food Processor is NOT involved in this recall. You may continue to use your Food Processor.</p>

To register:

Call Customer Service **1-877-339-2534**

Monday - Friday: 7:00AM to 11:00PM E.T.

Saturday - Sunday: 9:00AM to 5:30PM E.T.

OR Go Online to www.cuisinart.com/recall